4 CHANNEL THERMOCOUPLE TEMPERATURE SCANNER



Summary

- 4 Thermocouple measurement -100°C to 1200°C
- Rugged lightweight carbon fibre construction
- Accuracy 2.0°C over compensated range.
- Resolution 0.2°C
- Designed for autosport and wind tunnel applications.
- CAN bus communication protocol @1Mbit/s <1% bus loading.
- 0°C to 115°C operation

Revision:	Date:	Summary of Changes:	Author:
1.0	22/08/2014	First Issue	SB

Table 1. Mechanical Data

Mechanical	
Weight	30 grams
Dimensions	32x16.5x48mm
Temperature Connector	Miniature K-Type Thermocouple
Case	Carbon Fibre
Electrical Connector*	AS

^{*}Others available on request

Figure 1. Temperature Channel Identification




Table 2. Electrical Specifications

Electrical					
Supply Voltage	8-16V DC				
Current Consumption	<30mA				
Sampling Rate	10Hz				
CAN ID	Programmable				
CAN bus loading	0.3% maximum				

Table 3. Environmental Specifications

Environmental	
Supply Voltage	8-16V DC
Current Consumption	<30mA
Vibration	9g 100-1000Hz 24hrs
Media	Resistant to most motorsport fluids
Compensated Range	25°C to 100°C

Table 4. Electrical Harness Identification

Connector Identification				
1	CANH			
2	CANL			
3	SUPPLY			
4	GND			

CAN Message Data

Table 5. MUX ID

Identifi	er	N/A		
Rate		20Hz		
BYTE	DESCRIPTION		SCALING	Length
0	MUX		1	8

Table 6a. Sensor Data

Identifier		MUX=0x00						
Rate		10Hz						
BIT	BIT DESCRIPTION		Format	SCALING	Offset	Length [bits]	Units	
8-23	Temperature1		S16	1/5	0	16	$_{0}$ C	
24-39	Temperature2		S16	1/5	0	16	0C	
40-55	Temperature3		S16	1/5	0	16	0C	
56-63	BLANK		U8	1	0	8	N/A	

Table 6b. Sensor Data

Identifier		MUX=0x01						
Rate		10Hz						
BIT	IT DESCRIPTION		Format	SCALING	Offset	Length [bits]	Units	
8-23	Temperature4		S16	1/5	0	16	0C	
24-39	Unit Temperature		S16	1/10	0	16	0 C	
40-55	Serial No		U16	1	0	16	N/A	
56-63	BLANK		U8	1	0	8	N/A	

Configuration

The temperature scanner can be configured to set the CAN ID. This is applied immediately and is stored in non-volatile memory. (CAN ID=0x215).

Allow approximately 100mS between sending configuration messages to the node.

On power cycle settings including the system zero are stored in non-volatile memory.

